



Dining Shelter

Pole Set

Pole set

- 1 x Pole set + canvas Pole bag
- 6 x 3 way Corners,
- 4 x White Plain Poles Ridge
- 1 x Blue Double Reduction Roof Pole, 1x Blue Plain Roof Pole
- 2 x Green Double Reduction Side Roof Pole, 2 Green Plain Side Roof Poles
- 4 x Leg Top Poles, 4 x Leg Bottom Poles

“Fragile”

Hand made with care

Please handle with care

This product has been hand made in South Africa

Care & Maintenance Instructions for

Dining Shelter

DO

- * Check that you have all parts and components before and after your trip.
- * Allow your gazebo to dry completely before you pack it away for storage. This will discourage the formation of mildew. (Although the fabric is treated with mildew inhibitor, no fabric is completely mildew-proof.)
- * Secure your gazebo properly when pitching it, so that strong winds cannot dislodge and damage it.

DON'T

- *Store your gazebo on a concrete floor.
- *Pitch your gazebo near an open fire.
- *Spray your gazebo with insecticide.
- *Stand on the canvas cover.
- *Store your gazebo in a damp state and out of direct sunlight
- *Wash your gazebo with a detergent, don't bleach, don't dry clean, don't iron and don't tumble dry.
- *Pitch your gazebo under a tree which may drop sap or gum.
- *Expose your gazebo to any open flame. Candles, matches, camp- fire and any heating/cooking flame should be kept well clear of your gazebo.
- *Cleared off all loose threads, **DO NOT PULL** it, but cut it off with a scissor.

BEFORE USE

- *When preparing for a trip, pitch your gazebo fully at home, using the assembly checklist provided. This exercise will ensure that:
 - (1) The gazebo is undamaged.
 - (2) None of its sections or accessories is missing.
 - (3) You become familiar with the gazebo structure and how to pitch it.
- *Remember to take along extra gazebo pegs, guy ropes and storm straps.
- *When packing up your gazebo, check off all parts against your list so that nothing is left behind.

MAINTENANCE TIPS

Coastal Camping

- *Wash down all poles and other metal parts to prevent corrosion. **Dry well.**
- *Treat poles with a non corrosive agent before packing away. (Silicon base spray)

Stains

- *Sponge the stained area lightly. Do not use a scrubbing brush or any form of detergent, as these may affect the gazebo fabric.

LIMITATION

The warranty does not cover damage caused by normal wear and tear, neglect, unreasonable use, mildew, rotting, colour fading or **wind action.**

IMPORTANT INFORMATION

Customers must note that, although light shows through the tiny marks that are traditionally made along gazebo seams to guide the seamstress, this is entirely normal and does not affect the performance of the gazebo.

ACCEPTABLE PROCEDURE FOR HANDLING GAZEBO

Before returning your gazebo for repairs covered under warranty, ensure that it is **COMPLETELY CLEAN AND DRY.**

The clean, dry gazebo must be placed inside its carry bag and then inside a sealed box.

The product should be returned to where it was originally purchased, with the proof of purchased.

CARTAGE

The cost of delivering and fetching the gazebo sent for repair is **NOT Under Warranty** is for the account of the customer.

Thank you for purchasing a TENTCO Product