



No Boundaries

BUSH SHELTER

Congratulations on your purchase of this quality Tentco product. This tent is a frame tent with the tent suspended below the frame and the flysheet fitted over the top of the frame.

Go to www.tentco.co.za to view instructional videos on how to erect your tent

Tent & Frame assembly

1. Remove tent from the bag and lay flat on the ground or deck. Place the flysheet aside for later
2. The frame is assembled by matching the colour coded poles to their matching coloured corners.
3. Assemble the roof section of the frame, inserting only the top half of the legs
4. The tent is attached to the frame with the steel S-hooks with the extra section at front for verandah.
5. Attach the S hooks of the roof section to the roof frame and the top half of the leg poles.
6. Pull the flysheet into position over the frame.
7. Now lift the frame and insert the bottom half of the legs, one side at a time
8. Now the tent is up, open the door to allow air in and spread the groundsheet out until sits well.
Clip the remaining S hooks to the leg poles.
9. Pull the ground sheet tight and secure at all anchor points using straight pegs.
10. The flysheet frontlegs are anchored to the ground around the poles, guyropes are pulled outward and anchored to ground.
11. See overleaf for more instructions



Window flaps can be held up with poles to create extra cover. (poles available separately)

Dome tent, trailer or a vehicle can fit under the canopy


Dome tent available seperately




Bush Shelter




Build frame matching colour coded corners
Insert only bottom half of legs.
Place frame in desired position




Attach the tent to the inside of the frame
using the s-hooks.




Pull the flysheet over the frame into position




Insert bottom half of pole on one side first
and then the other side. Clip remaining
S-hooks to the frame



Ensure tent is sitting correctly on frame and
secure all peg points with the straight pegs



Erect the verandah section with the 3 poles
provided and secure all guy ropes with anchor
pegs.



Window flaps can be raised for extra shade
(Poles available separately, not included)

