



# POP UP GAZEBO PITCHING INSTRUCTIONS

1




Remove the frame & roof from the box

2



Pull the frame outwards to 50%

3




Centre of  
the frame



Centre of  
the roof


Put the roof on the frame  
(The centre of the roof is matched to the centre of the frame)

4




Connect the corners of the roof  
to the top corners of the frame  
using the Velcro

5



Pull the frame outwards so that  
the corners clips into place  
(If the frame is heavy, you could use shoulder  
power to push upwards)

6



Pull the legs upwards until the  
legs clip into place  
(Each leg has 4 height adjustments)

7



Repeat on the opposite side

## DISASSEMBLING INSTRUCTIONS:

1. Press the steel pole pin on the legs to lower the legs
2. Press the steel pole pin on in the corners to lower the corners
3. Push the frame inwards

